



Functions of Remote Controller

Model: WK14-R01

1. Press to turn **ON/OFF** Health Mode

1. Press to turn Power **ON/OFF**

1. **Press to select Mode:**
Cool, Dry, Fan, Auto & Heat
(For hot & cool AC only)

1. Press to turn **ON/OFF**
UP-DOWN Swing

1. Press to decrease temperature
2. Press this button and Left-Right
Swing button at a time and hold
for 3 seconds to see temperature
in Fahrenheit unit

1. Press to turn **ON/OFF** Turbo Mode
2. Press 6 times to turn **ON/OFF**
Auto Restart
3. Press 4 times to turn **ON/OFF**
Kids Mode

1. Press and hold for 3 sec to
show the room temperature
in IDU Display

1. **Press to toggle between
Fan Speed** (Low, Medium,
High & Auto)

1. Press to turn **ON/OFF** ECO Mode
2. Press 2 times to **Activate/Deactivate**
Voice Command (Only for
Oceanus Series)
3. Press 4 times to **Activate/Deactivate**
Wi-Fi Function
(Only for SMART models)
4. Press 4 times to **Activate/Deactivate**
Bluetooth Function
(Only for Bluetooth enabled models)

1. Press to increase temperature

1. Press to turn **ON/OFF** Left-Right
Swing

1. Press to **ON/OFF** Sleep Mode
2. Press 4 times to activate Frost
Clean (For Inverna, Diamond &
Oceanus Series)

1. Press to turn **ON/OFF** Display
2. **For Convertible Capacity
Air Conditioners:**
a. Press 4 times to enter Capacity 1*
b. Press 6 times to enter Capacity 2*
c. Press 2 times to enter Rated
Capacity*
*See special note for model wise
capacity details

1. Press to set **ON** time when **AC** is **OFF**
2. Press to set **OFF** time when **AC** is **ON**
3. Press and hold for 3 sec to **Lock/Unlock**
the Remote

1. Kids Mode & Auto restart **Activation/Deactivation**
work only in Cool Mode and Heat Mode

2. Frost Clean Function and Convertible Capacity
Selection work only in Cool Mode

3. Convertible Capacity details

For WSI-INVERNA (ULTRASAVER)-12C:

Rated Capacity=12k BTU (1 Ton), Capacity 1=9K BTU (0.75 Ton)
Capacity 2= 6K BTU (0.50 Ton)


For WSI-KRYSTALINE(PRETO)-18F:

Rated Capacity=18k BTU (1.5 Ton)
Capacity 1=12K BTU (1 Ton), Capacity 2= 9K BTU (0.75 Ton)



Functions of Remote Controller

Model: WX14-P01



Special Note :

1. Kids Mode & Auto restart Activation/Deactivation work only in Cool Mode and Heat Mode
2. Frost Clean Function and Convertible Capacity Selection work only in Cool Mode

3. ****Convertible capacity details**

For 12K, Rated Capacity (C0) = 12K BTU/hr (1.0 Ton)
Capacity 1 (C1) = 9K BTU/hr (0.75 Ton), Capacity 2 (C2) = 6K BTU/hr (0.50 Ton)
For 18K, Rated Capacity (C0) = 18K BTU/hr (1.5 Ton)
Capacity 1 (C1) = 12K BTU/hr (1.0 Ton), Capacity 2 (C2) = 9K BTU/hr (0.75 Ton)
For 24K, Rated Capacity (C0) = 24K BTU/hr (2 Ton)
Capacity 1 (C1) = 18K BTU/hr (1.5 Ton), Capacity 2 (C2) = 12K BTU/hr (1.0 Ton)

* For specific models only